



## Use Instructions

1. Stir **INSULCAST 125** thoroughly in its original container until uniform and any settled filler is completely reincorporated.
2. Weigh out required amount of **INSULCAST 125** and 22 parts **INSULCURE 23 FC** per 100 parts **INSULCAST 125**.
3. Mix thoroughly.
4. De-air (if necessary) at 29 in Hg. for 10 minutes.
5. Pour into mold, module or cavity.

## Cure Schedule

**INSULCURE 23 FC** - 16 TO 24 HOURS @ 25 °C. or 2 hours @ 80°C.

**Date** 08/2006

### **IMPORTANT:**

The following supersedes any provision in your company's forms, letters and papers. ITW POLYMER TECHNOLOGIES makes NO WARRANTY, WHETHER EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE FOR THIS PRODUCT. No statements or recommendations contained in the product literature are to be construed as inducements to infringe any relevant patent, now or thereafter in existence. UNDER NO CIRCUMSTANCES SHALL ITW POLYMER TECHNOLOGIES BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR OTHER DAMAGES FROM ALLEGED NEGLIGENCE, BREACH OF WARRANTY, STRICT LIABILITY OR ANY OTHER THEORY, ARISING OUT OF THE USE OR HANDLING OF THIS PRODUCT. The sole liability of AMERICAN SAFETY TECHNOLOGIES for any claims arising out of the manufacture, use or sale of its products shall be to refund the buyer's purchase price, provided such products have been demonstrated in ITW POLYMER TECHNOLOGIES sole opinion, to justify such refund.

### **HEALTH CAUTION:**

Avoid breathing possible fumes, mists and vapors which can cause severe respiratory damage. Use of NIOSH approved breathing apparatus is required for more than minimal exposure. Always work in areas with adequate ventilation to allow dissipation of polyamine and other chemical fumes, and where applicable, solvent fumes. Use of goggles, protective garments, rubber gloves, protective cream is required. If material gets into eyes, flush thoroughly with clean water for twenty (20) minutes; then seek medical treatment. Avoid skin contact. Material can cause contact dermatitis. Always wash exposed areas immediately, using warm water and soap, followed by rinsing with clean water. Observe all safety precautions. It is important when using solvent based materials or solvents to keep away from open flame or ignition source.

**PLEASE REFER TO MATERIAL SAFETY DATA SHEET FOR FURTHER FIRST AID INFORMATION. FOR CHEMICAL EMERGENCY, CALL CHEMTREC (DAY OR NIGHT) 800 424-9300.**